

POWERFLEX®

PART NUMBER

PFF5-901

DESCRIPTION

FRONT RADIUS ARM TO CHASSIS BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane Bushes
- 2 x Zinc Plated Mild Steel Washers
- 2 x Stainless Steel Sleeves
- 1 x Grease
- 4 x Zinc Plated Mild Steel Shells

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the arm from car.
2. Press the original bushes out of the arm and remove any dirt and check for any corrosion.
4. Press two of the steel shells into the bore of the arm from each side.
5. Note the location of the word 'Front' (as shown in Figure 1) on the bushing. Then apply some washing up liquid and press into shells with the lip with front on facing towards the front of the car.
6. Apply supplied grease to the knurled bore of the bush and press sleeve into the bore.
7. Refit arm to car, placing a washer on the end of the bush with 'Front' written on and tension all hardware to manufacturers recommended torque settings.



Figure 1



Figure 2

