



PART NUMBER

PFR5-726

DESCRIPTION

REAR DIFF REAR MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x bush
- 1 x stainless steel sleeve
- 1 x washer
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the diff to allow access to the bush, remove the original bush from the subframe. Clean any dirt or corrosion from the bore in the subframe and the mounting face of the diff.
2. The larger diameter of the new bush fits against the diff. Fit the new bush into the subframe with the larger diameter towards the front of the car. Apply some of the supplied grease to the bore and end faces of the bush.
3. Push the sleeve into the bush so the end is flush with the lower face at the diff end.
4. Refit the diff back into position using the new washer and original nut.

